




乾羅科技股份有限公司


Plug Master Industrial Co.,Ltd.




1. P8-006-29




4. Trim cable cross member.




2. Strip and removed 15mm of jacket.



5. Untwist and order pairs.



3. Separate the four pairs.



6. Trim. 9mm±1mm


Reason : Need the conductors to seat near the front of

the plug so the twists go far into the connector .



乾羅科技股份有限公司

*Plug Master Industrial Co.,Ltd.*



7. Slide cable into plug body.



9. Assembly process completed.



8. Crimp.



10. Assembly process completed.